

## SM1B



### Turn On

Press the power button on the right-hand side of the unit. You will hear the welcome message 'Sensear, Sounds Good To Me'. The green light on the right hand side of the unit will begin to flash slowly. You are in SENS Mode – Speech Enhancement Noise Suppression.

### Turn Off

Press and hold the power button on the right-hand side of the unit. You will hear the power down tones.

### Adjusting The Volume

Press the plus (+) or minus (-) sign button on the right-hand side of the unit to adjust for headset volume. For the highest volume continue to press the plus (+) button until you hear a double beep. The unit limits ear noise exposure to 82dB(A).

### Switching Modes

To switch between SENS and quiet mode press the power button once you have turned on the unit. The green light on the right hand side of the unit will flash intermittently in SENS mode and quickly in quiet mode. In quiet mode SENS audio will be muted.

### Two-way Radio Instructions

With the unit turned on connect to the 2-way radio by using the cable provided and turn the radio on, you should hear the message 'Two-Way Radio On'. Push to talk functionality can be used by pressing the push to talk button on the supplied radio cable.